



# K2 SETUP FOR XI EMULATOR .TSI


## I. SET MIDI CHANNEL TO 14



Hold down the POWER ON SETUP encoder [1] then power up using USB or X:LINK. The switch matrix LEDs will flash red three times to indicate setup mode.




Once in setup mode, switch 'A' (MIDI CH) will be illuminated. Press the POWER ON SETUP encoder to display the currently selected MIDI channel.




To change the MIDI channel number, rotate the POWER ON SETUP encoder. Set the MIDI channel number as shown then press the POWER ON SETUP encoder to return to setup mode (as above)


## 2. SET LATCHING LAYERS




In setup mode, rotate the POWER ON SETUP encoder clockwise to illuminate switch 'B' (LATCH LAYERS).



Press the POWER ON SETUP encoder to display the currently selected latching layers.



Rotate the POWER ON SETUP encoder until the switch matrix LEDs **ONLY** are illuminated red. Next press the POWER ON SETUP encoder to return to setup mode.



Press the EXIT SETUP switch [2] to exit programming mode. The switch matrix LEDs will flash red three times to indicate this.

2