

ALLEN&HEATH

Parts identification sheet



How to order parts

Parts must be ordered from our distributor in your territory. A list of international distributors can be viewed at <http://www.allen-heath.com/UK/distributors.asp>

UK parts must be ordered through an appointed A&H dealer or service centre. A list of UK service centres can be viewed at http://www.allen-heath.com/UK/service_centres.asp

PARTS IDENTIFICATION

How to order parts

Parts must be ordered from our distributor in your territory. A list of international distributors can be viewed at <http://www.allen-heath.com/UK/distributors.asp>

UK parts must be ordered through an appointed A&H dealer or service centre. A list of UK service centres can be viewed at http://www.allen-heath.com/UK/service_centres.asp

EXTERIOR PARTS

Side moulding
AA6741L AL6741R

Jack
AL6893

Burgundy
AJ6949

Blue
AJ2075A

Black
AJ6106A

Large white
AJ7545

Grey
AJ6278



Gain
AI8174

EQ HF LF
AI8004

EQ Hz
AI8005

EQ +/-
AI8004

Aux
AI8003

Pan
AI8008

Mono fader
003-940

Gain
AI8111

EQ HF LF
AI8004

Aux
AI8003

Pan
AI8008

Telco fader
003-940



XLR female i/p
AL2412


XLR male o/p
AL7505


Grey rect
AJ7179

Grey square
AJ7210


Grey round
AJ3955

Yellow
AJ8080






Mono out
AL4895




CRM speakers
CRM phones
MIX B level
AI8007




Guest phones
AI8007




Master fader
003-941




Burgundy
AJ6950




INTERIOR PARTS




Mono ip 003-900




Telco 1 003-901
Telco 2 003-933




Stereo 003-902




USB 003-903




Logic 003-904




Mix 003-905




Master 003-906



Meter R 003-907



Distribution 003-908



Connector 003-908