

iLive	80	112	144	176
AJ7532 PUSH BTN SKPMA GREY	29	41	49	57
AJ7533 PUSH BTN SKPMA WHITE	37	51	59	67
AJ7534 PUSH BTN SKPMA RED	5	6	6	6
AJ7535 PUSH BTN SKPMA BLACK	21	26	26	26
AJ7536 PUSH BTN SKPMA GREEN	26	41	49	57
AJ7537 PUSH BTN SKPMA BLUE	27	36	44	52
AJ 7398 push button guide iLive	145	200	233	265

iLive T	80	112
AJ7532 PUSH BTN SKPMA GREY	29	44
AJ7533 PUSH BTN SKPMA WHITE	45	62
AJ7534 PUSH BTN SKPMA RED	5	5
AJ7535 PUSH BTN SKPMA BLACK	12	13
AJ7536 PUSH BTN SKPMA GREEN	26	41
AJ7537 PUSH BTN SKPMA BLUE	27	36
AJ 7398 push button guide with LED window	160	116
AJ 7416 push button guide NO LED window	31	31