

MAINS VOLTAGE SETTING

The setting of the AC mains input voltage of the power supply must match the local mains supply in your area. To alter the setting you will require a soldering iron and some solder. Reconnect the terminals on the transformer according to the diagrams below. Remember to check the fuse for the correct type and rating .

