



GR1 example applications


VENUE




PUB/INN




CONFERENCE



INPUT EXPANSION



OUTPUT EXPANSION



More slaves can be added as required. Alarm source controls all units simultaneously. Disable internal links on source for output control on Master unit only.

More slaves can be added as required. Alarm source controls all units simultaneously. Switch inputs to Aux on slaves. Set links to pre-fade on Direct Outs.