

SQ Dante V2 card Release Notes

Product Version V1.1.1

- ❗ This update is for the SQ Dante V2 (M-SQ-DANT64) option card module. It cannot be used with any other card (including the M-SQ-SDANTE 'V1' card).

- ❗ Refer to www.allen-heath.com for instructions on how to update all devices in your system, including installation of the latest firmware for your console/processor and Dante expanders.

- ❗ The current version of SQ Dante V2 (M-SQ-DANT64) firmware supports the following:
 - Max number of DT168 / DT164-W on a Dante network: 16
 - Max number of DT168 / DT164-W within a Dante Domain Manager network: 8

V1.1.1	March 2020
---------------	------------

This was the first public release of SQ Dante V2 firmware.

Known Issues

- ID1326 Adjusting preamp settings after a DT device is disconnected can result in mismatched settings when reconnecting the device.
- ID953 The Dante Controller 'Identify' feature is not functional.

DT preamp controls might be missing or unavailable in the following circumstances:

- ID73 Adding DHCP to an active Dante network.
- ID78/71 Rebooting a device in a Dante Domain Manager network.
- ID75 Hot-plugging a DT device in large networks with several DT devices.
- ID77 3 or more SQ Dante cards sharing DT expanders.