

CONTENTS

Effective from serial number 501001 onwards.

This manual includes operating and service information for all models of the SR Series currently in production. Where differences between models exist, such as four bus and two bus models, this is indicated in the text.

CONTENTS		PAGE
Online version PART 1		
INTRODUCTION	Specification	3
	Service & Guarantee Info	4
	Electronic Performance	5
PANEL CONTROLS	Input Channel	6
	Group Channel	8
	Output Section	9
	Master Section	10
USE OF FACILITIES	Input Channel	11
	Group Channel	17
	Output Section	18
	Master Section	19
	Recording with the SR range	21
INSTALLATION	Connexions	22
	Connexion Diagrams	25
	Earthing	28
	AC Supply Voltages	29
USER CONFIGURED OPTIONS	Access to Mixer Circuits	30
	Service Notes	31
	Phantom Power	32
	Aux Send - Input Channel	33
	Fx Return	34
	Electronically Balanced O/Ps - Groups	35
	Stereo	36
	Mono	37
SERVICE INFORMATION	Spare Parts List	38
	Dimensions Diagrams	
	Schematic Diagrams	
	Block Diagram	

PSU not included in public version of document. Refer to hard copy version and distributor website version.