

ALLEN&HEATH

Parts identification sheet





Xone:02

How to order parts

Parts must be ordered from our distributor in your territory. A list of international distributors can be viewed at <http://www.allen-heath.com/UK/distributors.asp>



UK parts must be ordered through an appointed A&H dealer or service centre. A list of UK service centres can be viewed at http://www.allen-heath.com/UK/service_centres.asp


POTS FADERS & KNOBS:



ALLEN&HEATH XONE:02





Contour
AI8007 
AJ4346 

Phones socket
AL0328 


XLR male
AL2411

Jack socket
AL3410

Ground post
AL8106 


XLR female
AL2410 



Power switch
AB4502 

AC inlet
AL3458


Shorting plug
AL4396 

RCA phono
AI3753 


Button
AJ2887 

Fuse holder
AL3178

INTERIOR PARTS:



Main / Mic / Con. 002-763.
Single PCB with break-off sections.



Master / Mains / Meters 002-764