

ALLEN&HEATH

Parts identification sheet



ZED 2 bus FX

How to order parts


Parts must be ordered from our distributor in your territory. A list of international distributors can be viewed at <http://www.allen-heath.com/UK/distributors.asp>

UK parts must be ordered through an appointed A&H dealer or service centre. A list of UK service centres can be viewed at http://www.allen-heath.com/UK/service_centres.asp

EXTERIOR PARTS

Metal sides AA6740-L and -R

Nut & socket
(supplied with complete
socket)
AL6893



Plastic side
moulding left
AA6741-LJIT



Plastic side
moulding right
AA6741-RJIT



Knob Red
AJ6949



Nut pot
AB8050



Knob Blue
AJ2075A




Knob Black
AJ6106A



Knob Grey
AJ2078A



Feet
AK0102



Small
headphone
socket
AL5323

Knob
Yellow
AJ2079A



Switch cap
Rectangle
Black
AJ7182



Switch cap
Rectangle
White
AJ7180



Switch cap
Rectangle
Grey
AJ7179



Switch cap
Square
Grey
AJ7210



Switch cap
Round
Grey
AJ3955



Fader knob
Grey
AJ6278

Fader knob
Blue
AJ6237

Fader knob
Black
AJ8080

Fader knob
Red
AJ6950

XLR male
AL2413



XLR fem
AL2412



Jack sockets
AL6893




RCA phono
AL6830




MONO



STEREO




MASTER




INTERIOR PARTS



Effects (FX)
003-769JIT



USB module
003-664JIT



Headphones/
meter PCB
003-659JIT

Screws

